



EN

## Construction

The photo frame is made of durable polystyrene, ensuring solid protection for your photos and keepsakes. It is equipped with safe acrylic glass, double-sided scratch-resistant, guaranteeing durability and aesthetics. The frame is eco-friendly, made from environmentally friendly materials, and its universal design perfectly complements any interior. The option to hang it vertically or horizontally provides full flexibility in arrangement.

## Before Installation

Ensure that the frame and acrylic glass have no visible damage. Choose a dry, clean, and even wall, avoiding areas with excessive moisture. Prepare a level, pencil, and appropriate hooks or nails suitable for the weight of the frame.

## Step-by-Step Installation

**1.** Attach hooks or hammer nails into the marked spots on the wall. For concrete and brick walls, use wall plugs, while for wooden or plasterboard walls, hooks or nails will suffice. **2.** Once the hooks are secured, hang the frame using the mounts on the back, allowing for vertical or horizontal positioning. **3.** Finally, ensure the frame is stable and evenly mounted. Adjust its position as necessary.

## How to Clean the Frame

Clean the acrylic glass and frame with a soft, dry, or slightly damp cloth. Avoid using sharp tools, abrasive materials, or aggressive detergents that could damage the surface. Regular gentle cleaning will maintain the frame's aesthetic and protect the photos from dust.

### IMPORTANT! Observe precautions while using the product.

Ensure that the frame is properly mounted on a stable surface. Protect the product from impacts, scratches, and contact with sharp objects. Store in a dry, shaded place to maintain its durability and aesthetic appearance. Keep the product out of reach of children and pets to avoid accidental damage. Dispose of the product in accordance with local regulations after use. Failure to follow these recommendations may result in product damage or pose a safety risk to the user.

